# Roundness/Cylindricity Measurement ROUNDTEST RA-2200 Series

FORM MEASUREMENT





# **ROUNDTEST RA-2200**



The photo shows RA-2200 + vibration isolator with monitor arm.

All models are equipped with a highly accurate turntable that enables simple and accurate centering and leveling of the workpiece, which account for the majority of the essential setup work for measuring roundness/cylindricity.



The photo shows
RA-2200 +vibration isolator with side table


RA-2200AS/AH models are supplied as standard with an automatic centering and leveling turntable, freeing the operator from the centering and leveling task.


RA-2200DS/DH models are supplied as standard with a navigation function that quickly and simply guides the operator through the centering and leveling task, as though the task were being performed by an expert.

# Equipped with a highly accurate turntable that enables simple and accurate centering and leveling of the workpiece

The table provides high rotational accuracy (radial  $0.02+3.5H/10000 \mu m$ ; axial  $0.02+3.5X/10000 \mu m$ ), enabling the system to measure flatness and other characteristics, in addition to roundness/cylindricity, at a level that suits any application.

For centering and leveling support, you can select either the A.A.T. (Automatic Adjustment Table) or D.A.T. (Digimatic Adjustment Table).






Centering and leveling using an A.A.T. or D.A.T.\* can be integrated in the measurement procedure (part program). This can prevent mistakes such as forgetting to center and level during measurement and is intended to standardize measuring work through part-program measurement.

\*Models equipped with a D.A.T. require manual adjustment of centering and leveling misalignments.



# Sliding detector-unit holder provided as a standard feature

The detector-unit holder is equipped with a sliding mechanism, enabling one-touch measurement of a workpiece with a deep hole having a thick wall, which has been difficult with the conventional standard arm.



Sliding distance: 112 mm

The detector-unit holder can be stopped at a position sufficiently higher than the workpiece along the Z-axis, and then lowered and positioned to make measurements. Furthermore, internal/external diameters can be easily measured with the continuous internal/external diameter measurement function.


# High accuracy even at high positioning speeds

Continual development has resulted in the highest drive speed within the class.

- Vertical direction (Z-axis column): Max. 50 mm/s
- Radial direction: Max. 30 mm/s

### Continuous OD/ID measurement function

Continuous internal/external diameter measurement is possible without changing the detector position.





### Highly accurate repeat measurements

Mitutoyo's linear scales are incorporated into the X-axis positioning sensor, directly sensing the displacement of the drive unit to achieve highly accurate positioning, which is essential for repeat measurements.

#### **Spiral Measurement/Analysis**

The spiral-mode measurement function combines table rotation and rectilinear action allowing cylindricity, coaxiality, and other data to be loaded as a continuous data set.





# Safety mechanism provided as a standard feature



A safety mechanism is incorporated into the detector unit area. A collision-sensing function has been added to the detector unit (when it is in the vertical orientation) to prevent collision in the Z-axis direction. Additionally, an accidental collision prevention function, which stops the system when the detector unit displacement exceeds its range, has been added. When an accidental touch is detected, the dedicated analysis software (ROUNDPAK) senses the error and automatically stops the system.

### Partial circle measurement function

Even if a workpiece cannot be measured by physically rotating it by a full turn due to some obstruction (projection), segments of the circumference can be measured.

# **Roughness detector unit support**

When an optional roughness detector unit is incorporated into the system it can measure workpiece surface roughness in the circumferential direction around the  $\theta$ -axis, as well as roughness in the direct-drive directions along the X- and Z-axes with the table stopped.



# Measurement through X-axis tracking

Measurement while tracing is possible through a built-in linear scale in the X-axis. This type of measurement is useful when displacement due to form variation exceeds the measuring range of the sensor,

and X-axis motion is necessary to maintain contact with the workpiece surface.



# Retrofit kits can be used with models equipped with motorized detector-unit holders

Retrofit kits are available for the RA-2200AS and RA-2200AH to add the automatic measurement functionality found in their PLUS counterparts.

\*See page 4 for details.



# **ROUNDTEST RA-2200 PLUS**



The photo shows
RA-2200 PLUS+ vibration isolator with monitor arm.\*


\* Printer table is a special Accessory.



The photo shows
RA-2200 PLUS + vibration isolator with side table.

# Simple and accurate centering and leveling of the workpiece

The system comes standard with the A.A.T. (Automatic Adjustment Table) positioning and leveling function, freeing the operator from the task of centering and leveling the workpiece.



# High accuracy even at high positioning speeds

Continual development has resulted in the highest drive speed within the class.

- Vertical direction (Z-axis column): Max. 50 mm/s
- Radial direction: Max. 30 mm/s


# **Partial circle measurement function**

Even if a workpiece cannot be measured by physically rotating it by a full turn due to some obstruction (projection), segments of the circumference can be measured.

# **Detector unit orientation programmable for CNC measurement**

This function controls the orientation of the arm holding the detector unit (between vertical and horizontal) and the detector unit rotation mechanism (between 0 and 270 degrees in 1-degree increments), making it possible to continuously and automatically measure internal/external diameters as well as top/bottom surfaces. Additionally, a full-featured offline teaching function simplifies the creation of part programs.










## Continuous OD/ID measurement function

Continuous internal/external diameter measurement is possible without changing the detector position.



# **Highly accurate repeat measurements**

Mitutoyo's linear scales are incorporated into the X-axis positioning sensor, directly sensing the displacement of the drive unit to achieve highly accurate positioning, which is essential for repeat measurements.


# **Roughness detector unit support**


When an optional roughness detector unit is incorporated into the system it can measure workpiece surface roughness in the circumferential direction around the  $\theta$ -axis, as well as roughness in the direct-drive directions along the X- and Z-axes with the table stopped.



# **Spiral Measurement/Analysis**

The spiral-mode measurement function combines table rotation and rectilinear action allowing cylindricity, coaxiality, and other data to be loaded as a continuous data set.





# **Highly accurate turntable**

The table provides high rotational accuracy (radial 0.02+3.5 H/10000  $\mu$ m; axial 0.02+3.5X/10000  $\mu$ m), enabling the system to measure flatness and other characteristics, in addition to roundness/cylindricity, at a level that suits any application.

# Highly accurate positioning sensor

A Mitutoyo linear scale is incorporated into the X-axis positioning sensor, directly sensing the displacement of the drive unit to achieve highly accurate positioning, which is essential for repeat measurements. Furthermore, continual development has resulted in the highest drive speed within the class while achieving high accuracy even at high positioning speeds.

# **Detector unit II (option)**

This highly adjustable detector unit is for installation on motorized detector-unit holders.

Features of this detector unit include the ability to use alternative styli for the RA-2200\* and freely change the angle of the stylus.

\*See page 7 for alternative styli.



# **Measurement through X-axis tracking**

Measurement while tracing is possible through a built-in linear scale in the X-axis. This type of measurement is useful when displacement due to form variation exceeds the measuring range of the sensor, and X-axis motion is necessary to maintain contact with the workpiece surface.







# Roundness/Cylindricity measurement/Analysis software **ROUNDPAK**

**ROUNDPAK** provides simple manipulation using a mouse and icons

# Simple operations even with a full set of parameters and analysis functions

ODOODII

L L S S S S


테 즉 복 tzx ※ zĵ

● 端 과 옷


A wide variety of parameters including those for roundness/cylindricity, as well as flatness and parallelism, are provided as standard features. You can visually select these parameters using icons.

**ROUNDPAK** also comes with specialized functions, such as the design value best-fit analysis function, the harmonic analysis function, and a function for recording the peak or trough points on a

circumference. Data that has already been collected can be easily used for recalculation, or deleted.





Data deletion




# Freedom in laying out the graphics and data obtained from measurements

The customer can create reports in custom formats by specifying how the analysis results will be displayed, as well as the sizes and positions of graphics. The analysis result window can be directly utilized as a layout window. Since the measurement procedure, including the layout information, is saved, the entire process, from measurement start, calculation, result saving, and finally to printing, can be automatically executed.









# A wide variety of graphics functions

Analysis results such as cylindricity and coaxiality can be visually expressed in 3D graphics.



# Off-line measurement procedure programming function



Patent registered in Japan, USA Patent pending in Europe

An offline teaching function is provided to create a part program (measurement procedure) without an actual measurement target, enabling the user to virtually execute the measurement operation in a 3D simulation window. You can also display warnings\* about the risk of collision on the simulation window.

\* This function is for **RA-2200 PLUS** only.

# **StatusMonitor**

Remote machine monitoring





# MitutoyoLauncher support

Quick Launcher is provided as a standard feature. This enables simple and intuitive operation, so part programs can be run easily. Part programs can also be run by scanning barcodes or QR codes.

# Harmonic tolerance verification / Velocity analysis

Analysis of bearing sliding surfaces is provided as a standard feature.









# **Optional Accessories**

# ■ Styli for RA-2200 (Option)

	10. 18.1 <b>2200</b> (option)				
Туре	Standard (Standard accessory)	Notch	Deep groove	Corner	Cutter mark
Order No.	12AAL021	12AAL022	12AAL023	12AAL024	12AAL025
Stylus tip	ø1.6 mm tungsten carbide	ø3 mm tungsten carbide	SR0.25 mm sapphire	SR0.25 mm sapphire	tungsten carbide
Dimensions (mm)	a1.6 tungsten carbide 66 67.5	93 tungsten carbide 66 68.2	65 62 63 64 580.25 (sapphire)	58.8 58.8 580.25 (sapphire)	Hard metal 65
Туре	Small hole (ø 0.8)	Small hole (ø 1.0)	Small hole (ø 1.6)	Extra small hole (Depth 3 mm)	ø 1.6 mm ball
Order No.	12AAL026	12AAL027	12AAL028	12AAL029	12AAL030
Stylus tip	ø 0.8 mm tungsten carbide	ø 1 mm tungsten carbide	ø 1.6 mm tungsten carbide	ø 0.5 mm tungsten carbide	ø 1.6 mm tungsten carbide
Dimensions (mm)	00.8 tungsten carbide 90.6 \$\frac{12}{66}\$	ø1 tungsten carbide	el 5 ungsten cabide C1 C5	ø0.5 tungsten carbide ø0.3	ø1.6 tungsten carbide  ø1.2  20  66
Туре	Disk Crank (ø 0.5)		Crank (ø1.0)	Flat surface	2X-long type *1
Order No.	12AAL031	12AAL031 12AAL032		12AAL034	12AAL035
Stylus tip	ø 12 mm tungsten carbide	ø0.5 mm tungsten carbide (Depth 2.5 mm)	ø1 mm tungsten carbide (Depth 5.5 mm)	tungsten carbide	ø 1.6 mm tungsten carbide
Dimensions (mm)	0.5 66 80 5 Jungsten carbide)		e0.7 66 67.5	68 Hard metal 3 0.5 0.5 66	91.6 tungsten carbide 146. 147.5
Туре	2X-long type notch *1	2X-long type deep groove *1	2X-long type corner *1	2X-long type cutter mark *1	2X-long type Small hole *1
Order No.	12AAL036	12AAL037	12AAL038	12AAL039	12AAL040
Stylus tip	ø 3 mm tungsten carbide			tungsten carbide	ø1 mm tungsten carbide
Dimensions (mm)	e3 tungsten carbide	145 145 146 SR0 25 (sapphire)	138.3 136.7 ml 146 (SR0.25 (sapphire)	Hard metal 145	ø1 tungsten carbide
Type	3X-long type *1	3X-long type deep groove *1	Stylus shank	Stylus shank(standard groove)	Stylus shank(2X-long groove)*1
Order No.	12AAL041	12AAL042	12AAL043	12AAL044	12AAL045
Stylus tip	ø1.6 mm tungsten carbide			For mounting CMM stylus (mounting thread M2)	For mounting CMM stylus (mounting thread M2)
Dimensions (mm)	227.5 226 227.5 226 5R0.25 (sapphire)		M2 Depth 5 56	68.5 58 M2 66	148.5 SM2 146






<sup>\*1:</sup> Measuring is only possible in the vertical direction.
\*2: Customized special interchangeable styli are available on request. Please contact any Mitutoyo office for more information.



# ■ Styli for RA-2200 PLUS



Туре	ø 1.6 mm ball	ø0.8 mm ball	ø0.5 mm ball	Deep groove	Deep hole B	
Order No.	12AAE303	12AAE304	12AAE305	12AAE308	12AAE307	
Stylus tip	ø 1.6 mm tungsten carbide	ø 0.8 mm tungsten carbide	.8 mm tungsten carbide ø 0.5 mm tungsten carbide ø 1.6 mm		ø 1.6 mm tungsten carbide	
Dimensions (mm)	220 75 33 44.6	12 33 442	3 7 7 8 33 44.1	44.7 5 1.2 5 33 43.8	100 100 100 100 100 100 100 100 100 100	

# Options common to the RA-2200 and RA-2200 PLUS



# Centering chuck (key operated)

#### 211-014

Suitable for holding longer parts and those requiring a relatively powerful clamp.

ø157 x 70.6 mm

•Mass: 3.8 kg



# Centering chuck (ring operated)

#### 211-032

Suitable for holding small parts with easy-to-operate knurled-ring clamping.

- •Holding capacity:
  Internal jaws: OD = Ø1-Ø36 mm,
  ID = Ø16-Ø69 mm
  External jaws: OD = Ø25-Ø79 mm
- •External dimensions (DxH): ø118 x 41 mm
- •Mass: 1.2 kg



# Micro-chuck

#### 211-031

Used for clamping a workpiece (less than Ø1 mm dia.) that the centering chuck cannot handle.

- Holding capacity: Ø02-Ø1.5 mm
   Fytornal dimensions (DyH):
- •External dimensions (DxH): ø107 x48.5 mm
- •Mass: 0.6 kg



# Magnification calibration gage

#### 211-045

Used for normalizing detector magnification by calibrating detector travel against displacement of a micrometer spindle.

- Maximum calibration range: 400 µm
- •Graduation: 0.2 µm
- •External dimensions (WxDxH): 235 (max) x 185 x 70 mm
- •Mass: 4 kg

# Cylindrical square 350850

- •Straightness: 1 µm
- •Cylindricity: 2 µm
- •External dimensions (DxH): @70 x 250 r
  - ø70 x 250 mm
- •Mass: 7.5 kg





# **Specifications**

# RA-2200

Model No.			RA-2200AS	RA-2200DS	RA-2200AH	RA-2200DH	
	Datational accuracy	Radial direction	(0	0.02+3.5H/10000) µm H: probi	ng height (mm)		
Turntable unit	Rotational accuracy	Axial direction	(0.02+3.5X/10000) μm X: Distance from the center of rotation (mm)				
	Rotating speed		2, 4, 6, 10 rpm				
	Table effective size		ø235 mm	ø200 mm	ø235 mm	ø200 mm	
	Centering/leveling adjustment		A.A.T	D.A.T	A.A.T	D.A.T	
	Centering adjustment range		±3 mm	±5 mm	±3 mm	±5 mm	
	Leveling adjustment range		±1°				
	Max. loading mass		30 kg				
	Max. probing diameter		300 mm				
	Max. loading diameter		580 mm				
	Straightness accuracy		0.10 μm/100 mm (λ c2.5)	0.15 μm/300 mm (λ c2.5)	0.10 μm/100 mm (λ c2.5) 0.25 μm/500 n		
	Parallelism to rotation center		0.7 μm/300 mm (Referential generatrix line) 1.2 μm/500 mm (Referential generatrix line)			ential generatrix line)	
Vertical drive unit	Traverse speed		Max. 50 mm/s (during measurement: 0.5/1/2/5 mm/s)				
(Z-axis)	Max. probing height	OD	300 mm		500 mm		
		ID	300 mm 500 mm		mm		
	Max. probing depth (with standard stylus)		85 mm for ø32 mm or more, 50 mm for ø7 mm				
	Straightness accuracy		0.7 μm/150 mm (λ c2.5)				
Radial drive unit	Horizontal to rotation center		1.0 μm/150 mm (Referential generatrix line)				
(X-axis)	Traverse range		175 mm (-25 mm to +150 mm from the rotation center )				
	Traverse speed		Max. 30 mm/s (during measurement: 0.5/1/2/5 mm/s)				
	Measuring force		10 $\sim$ 50 mN (switching 5-step)				
	Stylus design, material		ø1.6 mm tungsten carbide ball				
Detector	Measuring range	Standard	±400 μm/±40 μm/±4 μm				
Detector		Follow	±5 mm				
	Other		In/out switching feature, Measuring force switching feature (5-step), Stylus angle scale markings (±45°),				
			Collision detection function for Z-axis direction, Sliding detector holder (plus 3 rotational positions)				
	Power supply		100V ∼ 240 V				
Other	Air pressure		0.39 MPa				
Other	Air consumption		30 L/min in standard state (80 L/min or more as air source)				
	Mass (main unit)		180	180 kg 200 kg		kg	

# RA-2200 PLUS

Model No.			RA-2200 PLUS			
Z-axis			Standard column (Vertical travel: 300 mm)	High column (Vertical travel: 500 mm)		
	Datational account	Radial direction	(0.02+3.5H/10000) µm H: probing height (mm)			
	Rotational accuracy	Axial direction	(0.02+3.5X/10000) μm X: Distance from the center of rotation (mm)			
	Rotating speed		2, 4, 6, 10 rpm			
	Table effective size		ø235 mm			
Turntable unit	Centering/leveling adjustment		A.A.T			
Turritable uriit	Centering adjustment range		±3 mm			
	Leveling adjustment range		±1°			
	Max. loading mass		30 kg			
	Max. probing diameter		256 mm (OD), 344 mm (ID)			
	Max. loading diameter		580 mm			
	Straightness accuracy		0.10 $\mu$ m/100 mm ( $\lambda$ c2.5) 0.15 $\mu$ m/300 mm ( $\lambda$ c2.5)	0.10 $\mu$ m/100 mm ( $\lambda$ c2.5) 0.25 $\mu$ m/500 mm ( $\lambda$ c2.5)		
	Parallelism to rotation center		0.7 µm/300 mm (Referential generatrix line)	1.2 µm/500 mm (Referential generatrix line)		
Vertical drive unit	Traverse speed		Max. 50 mm/s (during measurement: 0.5/1/2/5 mm/s)			
(Z-axis)	Max. probing OD		300 mm	500 mm		
	height	ID	300 mm	500 mm		
	Max. probing depth (with standard stylus)		26 mm for ø12.7 mm or more, 104 mm for ø32 mm			
	Straightness accuracy		0.7 μm/150 mm (λ c2.5)			
Radial drive unit	Horizontal to rotation center		1.0 μm/150 mm (Referential generatrix line)			
(X-axis)	Traverse range		175 mm (-25 mm to +150 mm from the rotation center)			
	Traverse speed		Max. 30 mm/s (during measurement: 0.5/1/2/5 mm/s)			
	Measuring force		40 mN			
	Stylus design, material		ø1.6 mm tungsten carbide			
Detector	Measuring range	Standard	±400 μm/±40 μm//			
Detecto.		Follow	±5 mm			
	Other		Accidental touch function			
			Measuring direction : one direction			
	Power supply		100 V ~ 240 V			
Other	Air pressure		0.39 MPa			
	Air consumption		30 L/min in standard state (80 L/min or more as air source)			
	Mass (main unit)		180 kg 200 kg			








Unit: mm


# **Dimensions**

# Dimensions

RA-2200



#### **RA-2200 PLUS**




# with vibration isolator and side table

830 Max. 800 in width

# with monitor arm\*

**(** 



\* Printer table is a special accessory.

**(** 





#### Whatever your challenges are, Mitutoyo supports you from start to finish.

Mitutoyo is not only a manufacturer of top quality measuring products but one that also offers qualified support for the lifetime of the equipment, backed up by comprehensive services that ensure your staff can make the very best use of the investment.

Apart from the basics of calibration and repair, Mitutoyo offers product and metrology training, as well as IT support for the sophisticated software used in modern measuring technology. We can also design, build, test and deliver measuring solutions and even, if deemed cost-effective, take your critical measurement challenges in-house on a sub-contract

Note: Product illustrations are without obligation. Product descriptions, in particular any and all technical specifications, are only binding when explicitly agreed upon

MITUTOYO and MiCAT are either registered trademarks or trademarks of Mitutoyo Corp. in Japan and/or other countries/regions. Other product, company and brand names mentioned herein are for identification purposes only and may be the trademarks of their respective holders.

Our products are classified as regulated items under Japanese Foreign Exchange and Foreign Trade Law. Please consult us in advance if you wish to export our products to any other country. If the purchased product is exported, even though it is not a regulated item (Catch-All controls item), the customer service available for that product may be affected. If you have any questions, please consult your local Mitutoyo sales office.

# **Mitutoyo**

# Mitutoyo Asia Pacific Pte. Ltd.

Company Reg No. 197800892N

24 Kallang Avenue, Mitutoyo Building, Singapore 339415

Tel: (65) 6294 2211 Fax: (65) 6299 6666 E-mail: mapsg@mitutoyo.com.sg



# Mitutoyo (Malaysia) Sdn. Bhd.

Mah Sing Integrated Industrial Park, 4, Jalan Utarid U5/14, Section U5, 40150 Shah Alam, Selangor, Malaysia Tel: (60) 3-7845 9318 Fax: (60) 3-7845 9346

E-mail: mmsb@mitutoyo.com.my Penang Branch Tel: (60) 4-641 1998

Fax: (60) 4-641 2998 Johor Branch
Tel: (60) 7-352 1626

Fax: (60) 7-352 1628

MAP • 1281(5)

#### Mitutoyo (Thailand) Co., Ltd.

76/3-5, Chaengwattana Road, Kwaeng Anusaowaree, Khet Bangkaen, Bangkok 10220, Thailand Tel: (66) 2080 3500 E-mail: office@mitutovo.co.th Chonburi Branch Tel: (66) 2080 3563 Tel: (66) 2080 3565

#### PT. Mitutoyo Indonesia

Jalan Sriwijaya No.26 Desa cibatu Kec. Cikarang Selatan Kab. Bekasi 17530, Indonesia Tel: (62) 21-2962 8600 Fax: (62) 21-2962 8604 E-mail: ptmi@mitutoyo.co.id Tel: (62) 778-4888 000 Email: ptmi-batam@mitutoyo.co.id

# Mitutoyo Vietnam Co., Ltd.

1st & 2nd Floor, MHDI Building, No. 60 Hoang Quoc Viet Road, Nghia Do Ward, Cau Giay District, Hanoi, Vietnam Tel: (84) 24-3768 8963 Fax: (84) 24-3768 8960 E-mail: mvc@mitutovo com vn Ho Chi Minh City Branch Tel: (84) 28-3840 3489 Hai Phong Branch
Tel: (84) 22-5398 9909

# Mitutoyo Philippines, Inc.

Unit 1B & 2B LTI, Administration Building 1. Annex 1, North Main Avenue Laguna Technopark, Biñan, Laguna 4024, Philippines Tel: (63) 49-544 0272 E-mail: mpi@mitutoyo.com.ph